

Instructions ELS Vision

Use arrows to decide what to show.

Information (Information) > Register (Register) > Logga in (Log in) > Språk (Language) (as of now, only Swedish is available).

For more information

For "Läs mer" (read more), choose info. Confirm with **OK** or choose **BACK** to go back.

Put the tag to the reader for personal information.



Booking

1. Put the tag to the reader, personal info is shown. Choose alternatives or **OK** to book.

2. Mark Boka (Book) and confirm with **OK**. Booking options are shown. Choose your preferred option and confirm with **OK**.

3. Choose your preferred option and the calendar will be shown. Choose day and time, press **OK**.

4. Move the marking (blinking blue frame) **1,2** and choose an option. Confirm with **OK**.

The booking is done when an image with "Bokning OK" (Booking OK) is shown. Press **BACK** to move back or log out.



Cancel booking

Put the tag over the reader, mark Avboka (Cancel booking) and confirm with **OK**. Choose what you want to cancel, confirm with **OK**. Cancellation is complete when an image with "Avbokning OK" (Cancellation OK) is shown. Press **BACK** to go back.

Send messages and error-/damage reports

1. Put the tag over the reader. Personal info is shown. Choose "Välj alternativ eller OK, för tjänster" (Choose alternatives or OK for services).

2. Mark "Tjänster" (Services), confirm with **OK**.

3. Choose "Skicka meddelande" (Send message), confirm with **OK**.

4. From here, choose a message-alternative and confirm with **OK**. Push **BACK** to return.

